

## **Dragonforce 65 Tuning Guide**

| Phil Burgess<br>1st July 2020 | M - 0413 200 608 E - philb@psk.com.au  | A+                                       | Α   | В  | C  |
|-------------------------------|--|--|---|--|--|
| Estimated wind ran            | ge - depends on wave action and tacking ability  | 0 - 10 kts                               | 8 - 15 kts  | > 15 kts                                       | > 20 kts                                       |
| Mast Gate                     | Distance from Jib Pivot Eyelet to front of Mast (Can also use gate control as a ram to induce mast bend without changing forestay).  | <b>3rd</b> line (175 mm)                 | 4th Line<br>(176 mm)                                    | 5th Line<br>(177 mm)                           | Max Aft<br>(178 mm)                            |
| Mast Rake                     | A+ From backstay crane hole to top of backstay hook A, B, C From top of Forestay tang to top of backstay hook.   | 951 mm. From soft to firm as wind builds | 785 mm.<br>Slightly firmer backstay &<br>tight forestay | 698 mm.<br>Firmer backstay & tight<br>forestay | 620 mm.<br>Firmer backstay & tight<br>forestay |
| Mast Bend                     | Tension Backstay so Mast bend matches Mainsail luff, so sail<br>easily flops from side to side when tilted   | Soft settings                            | Match luff round  | Match luff round                               | Match luff round                               |
| Boom Outhaul Sail<br>Depth    | At centre of Jib Boom deepest point  | 20-25 mm,<br>15 mm at top of range       | 15-20 mm  | 15-20 mm                                       | 10-15 mm                                       |
|                               | At centre of Main Boom deepest point   | 25-30 mm,<br>15 mm at top of range       | 15-25 mm  | 15-20 mm                                       | 10-20 mm                                       |
| Boom - Close<br>hauled        | Jib - from Mast centre to end of Jib Boom. Place small<br>mark on deck   | 38-43 mm                                 | 40-45mm   | 40-45mm  | 40-45mm  |
|                               | Main - from centreline at end of Main Boom. (Adjust Tx for exponential adjustment for last 20 mm sheet travel for high and low pointing mode)                                      | 8-15 mm                                  | 10-20 mm  | 15-25 mm                                       | 15-25 mm                                       |
| Leech Twist                   | Jib - from Centre of Mast to leech at mid point of jib leech,<br>Draw small dot on leech at halfway point. (Adjust to balance<br>rig. Let out if bearing away - In if rounding up) | 50-60 mm,<br>more twist at top of range  | 40-50 mm  | 30-45 mm                                       | 35-45 mm                                       |
|                               | Main - from Backstay to leech at middle batten. Adjust to minimise rounding up. In if bearing away - Out if rounding up  | 40-55 mm,<br>more twist at top of range  | 65-75 mm  | 55 mm  | 45 mm  |

Adapted from Tuning experience, Assembly Manual & Soch Guide

| Common Mistake | Late for Start    | Test angles both sides and Keep clear of other boats                                |  |
|----------------|-------------------|---|--|
|                | Hit Marks         | Blink eyes approaching marks. Allow wider clearances, minimise port tack approaches |  |
|                | Wrong Course      | Pay attention!  |  |
|                | Hit Other boats   | Correct protest and remember Sail Nos and incident                                  |  |
|                | Boat not balanced | Use Guide to avoid rudder movement, pre-race testing against another boat           |  |
|                | Broke Start       | Practice Timing and acceleration rate   |  |
|                | 1.                |   |  |